



Note 1: A and B—style elbows are available in 80° and 45° angles. A—style elbows direct water away from the building. B—style elbows direct water alongside the building.

Note 2: Install all elbows with a minimum of two pop rivets per side. Place overlapping joints in progressive order to ensure a water shedding joint.

DATE: JANUARY 2013	DRAINAGE DETAILS
DRAWN BY: ENG. DEPT.	METAL DOWNSPOUT ELBOWS
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF